



Start with your DC stranded or AC solid wire pairs. Strip 0.45" off the end of each wire.



Make sure stranded wire is not frayed or twisted before inserting.



Insert wire into push-in connector.



Insert wire far enough so that wire ends are completely inside the plastic connector housing. Push hard.



Finished product should look similar to this. Test for continuity with a voltage tester.

ECO LIGHT
LED Lighting Solutions
EcoLightLED.com

© COPYRIGHT 2010 ECO LIGHT LED