



RECEIVER CONNECTION INSTRUCTIONS



LINKING REMOTE CONTROL TO THE RECEIVER

- 1 Connect Receiver to Power Supply and RGB LED Lights
 - 2 Install 2 AAA Batteries in the back of Remote Control
 - 3 Push button on Receiver, then Receiver Signal Indicator will flash
 - 4 Push the RED UP button on Remote
- Remote Control and Receiver are now linked together



OPERATING INSTRUCTIONS

- RF Signal Indicator
- Select one of 4 built in Modes
- Power Button to turn on RGB LED Lights
- Speed Up or Down - 8 Levels
- Brightness Up or Down - 0 to 100%
- Dimming Up or Down for RED LEDs - 0 to 100%
- Dimming Up or Down for Green LEDs - 0 to 100%
- Dimming Up or Down for Blue LEDs - 0 to 100%
- 4 Built in color changing Modes:
 - 1) RGB Color Fade
 - 2) 7 Color Jumpy Color Change
 - 3) 7 Color Fade Change
 - 4) 7 Color Random Fade Change

Copyright © 2010 Eco Light LED